



In order to ensure a proper reading when using this tool, it is important to use steady & even pressure while measuring preload. Turning too quickly can give a false reading of the preload being higher than it actually is, while turning too slowly can provide a reading that is lower. We also recommend you rotate the pinion both directions when taking your preload measurements.