



PART NUMBER	DESCRIPTION	QTY
COMPUK-01	COILED HOSE	1
COMPUK-02	FEMALE COUPLER	1
COMPUK-03	MALE COUPLER	1
COMPUK-04	MALE CONNECTOR	1
COMPUK-05	FEMALE CONNECTOR	1
COMPUK-06	MALE RUN TEE	1
COMPUK-07	LOCK ON CHUCK	1
COMPUK-08	TEFLON TAPE	1

Couplers will accept all industrial and Acme type connectors.

Kit is designed for installation with onboard compressor in use with air operated lockers.

#### Installation Steps:

- Relieve air pressure from compressor system.
- Remove all wire connections from compressor pressure switch.
- Remove pressure switch from compressor reservoir.
- Apply supplied Teflon tape to male threads of the male run tee.
- Thread male run tee into compressor reservoir and tighten.
- Clean pressure switch threads and reapply Teflon tape.
- Thread pressure switch into one of the male tee ports and tighten.
- Apply Teflon tape to thread of male coupler.
- Thread male coupler into male run tee and tighten.
- Thread female connector onto one end of coiled hose and tighten.
- Thread female universal coupler onto other end of hose and tighten.
- Apply Teflon tape to male connector
- Thread male connector into the lock on tire chuck and tighten.

**\*\*NOTE\*\*** Tire chuck may be directly threaded onto hose if hose quick disconnect will not be used.